

TrekStor - eBook Player 7M - Firmware-Update

1. Please connect your eBook Player with an USB port of your PC.
2. Double click the „LiveSuit_v1.07_7M.exe“ file.
3. In the following window please make sure that you click **„Continue Anyway“**, in order to install all required drivers for this update. Now all required data are automatically unpacked into the directory „LiveSuit_1.07“.



4. Open the folder „LiveSuit_1.07“.


Name	Größe	Typ	Geändert am
LiveSuit_1.07		Dateiordner	24.03.2011 14:26
LiveSuit_v1.07_7.exe	14.412 KB	Anwendung	14.03.2011 16:28
eBook_Player_7_Firmware_eBP7-1.0.3-20110308.img	36.117 KB	IMG-Datei	08.03.2011 21:11

5. Start the update program by double clicking the „LiveSuit.exe“ file.


Name	Größe	Typ	Geändert am
Erase		Dateiordner	24.03.2011 14:26
History		Dateiordner	24.03.2011 14:26
product		Dateiordner	24.03.2011 14:26
sync		Dateiordner	24.03.2011 14:26
update		Dateiordner	24.03.2011 14:26
UsbDriver		Dateiordner	24.03.2011 14:26
work		Dateiordner	24.03.2011 14:26
ACmd.dll	60 KB	Programmbibliothek	24.03.2011 14:26
APIpe.dll	92 KB	Programmbibliothek	24.03.2011 14:26
AwPluginVector.dll	28 KB	Programmbibliothek	24.03.2011 14:26
Config.dll	40 KB	Programmbibliothek	24.03.2011 14:26
crc32.dll	32 KB	Programmbibliothek	24.03.2011 14:26
drvinstaller_IA64.exe	51 KB	Anwendung	24.03.2011 14:26
drvinstaller_X64.exe	27 KB	Anwendung	24.03.2011 14:26
drvinstaller_X86.exe	34 KB	Anwendung	24.03.2011 14:26
eFex.dll	44 KB	Programmbibliothek	24.03.2011 14:26
encode.dll	32 KB	Programmbibliothek	24.03.2011 14:26
Filelist.txt	1 KB	Textdokument	24.03.2011 14:26
IdFactory.dll	36 KB	Programmbibliothek	24.03.2011 14:26
ImgDecode.dll	44 KB	Programmbibliothek	24.03.2011 14:26
KSDDecode.dll	100 KB	Programmbibliothek	24.03.2011 14:26
LangPlg.dll	52 KB	Programmbibliothek	24.03.2011 14:26
LiveSuit.cfg	1 KB	CFG-Datei	24.03.2011 14:26
LiveSuit.dat	4 KB	DAT-Datei	24.03.2011 14:26
LiveSuit.exe	1.264 KB	Anwendung	24.03.2011 14:26
LiveSuit.exe	8 KB	LAN-Datei	24.03.2011 14:26
LiveSuitCN.CHM	1.896 KB	Kompilierte HTML-Hilf...	24.03.2011 14:26
LiveSuitEN.CHM	1.896 KB	Kompilierte HTML-Hilf...	24.03.2011 14:26
LiveSuitTW.CHM	1.896 KB	Kompilierte HTML-Hilf...	24.03.2011 14:26
Phoenix_Elf.dll	24 KB	Programmbibliothek	24.03.2011 14:26
Phoenix_Fes.dll	36 KB	Programmbibliothek	24.03.2011 14:26
roottools.dll	36 KB	Programmbibliothek	24.03.2011 14:26
sdata.dll	60 KB	Programmbibliothek	24.03.2011 14:26
single.dll	92 KB	Programmbibliothek	24.03.2011 14:26
wizard.cfg	13 KB	CFG-Datei	24.03.2011 14:26
ZipModule.dll	300 KB	Programmbibliothek	24.03.2011 14:26

6. After the LiveSuit window has opened click on the top left corner onto „**Select Firmware**“.


Note: If the program window is not displayed / cannot be seen, please click the "Live-Suit" icon in the system tray in the bottom right at the taskbar.




7. Choose now the „.img“ file and confirm the process by pressing „**Open**“.




8. The text inside the Image field shows you that the firmware file was loaded successfully.




9. In the next step click onto „**Update Firmware**“ in order to start the firmware update




10. A notification window opens, which reminds you to backup your most important data. Afterwards click „**Yes**“ in order to continue the firmware update.




11. The note on the bottom of the window shows that the update mode was initiated successfully.




12. If you are updating your eBook Player for the first time, you are asked during the process to install an USB driver. Prevent in the first step on the displayed window the connection buildup to the Windows Update by choosing „**No, not this time**“. Confirm the process afterwards by pressing „**Next**“.




13. In the next step choose the second point „**Install from a list or a specific location (Advanced)**“ and confirm the process once more by pressing „**Next**“.




14. Please take the above displayed settings and click onto „Browse“ in order to search for the right driver. Choose the folder „UsbDriver“ inside the „LiveSuit_1.07“ directory. Confirm afterwards with „Next“.



15. Click „Continue Anyway“ when the next notification window opens.




16. The driver software is now installed automatically.




17. As soon as the installation is finished click onto „**Finish**“.




18. While the driver software is installed, the following notification window opens and asks, if you would like to format the eBook Player. Confirm that window by pressing „No“.
(Caution: If you click „Yes“ all saved data will be deleted from your eBook Player!)




19. LiveSuit starts now to install the firmware update onto your eBook Player.



20. When the process was finished successfully, the note „Update success“ (Process: 100%) will appear. Press „OK“ in order to finish the firmware update.



21. Press „Exit“ to quit the program.



22. Please wait until the eBook Player has initialized itself completely.

23. Now the firmware update is completed.

24. Disconnect the eBook Player from the USB port of your PC.

25. Ready.